


## SonicWALL Routers


### Using HTTP(S)

We would recommend using HTTPS rather than HTTP for transferring your devices configuration as the latter provides no encryption. The procedure for getting the configuration from the device using HTTP(S) is as follows:

1. Using your favorite web browser, connect to the HTTP(S) service provided by your Juniper IDP for remote management. You can do this by entering "https://" (recommended) or "http://" followed by your devices IP address.
2. Select **Settings** from the menu on the left hand side.



3. Click **Export Settings...**
4. Click **Export**



5. Choose **Save File** and finally click **OK**